


# ROLLEI RPN PRINT NEUTRAL

ROLLEI RPN Print Neutral is the ideal paper developer for all standard tasks in the photo laboratory. It can be used universally and is equally suitable for PE/RC and FB papers. RPN produces a neutral image tone with deep blacks of consistent color and provides excellent fog resistance. Even with high dilution and high processing throughput, the good properties of this developer are fully retained. RPN is suitable for tray and machine processing.



## Dilution 1 + 9:



900ml water + 100ml RPN = 1l working solution  
Temp. 20°C / 68°F | Agitate regularly

## AVAILABLE SIZES



**Warning** | Contains Hydroquinone. Causes serious eye irritation. Suspected of causing cancer. Harmful in contact with skin. **Keep out of reach of children.** If in eyes: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Wear protective gloves/clothing, eye/face protection. If swallowed: Immediately call a poisoncenter or doctor/physician. If medical advice is needed, have product container/label at hand.

APPLICATION	DILUTION	TIME (20°C/68°F)	CAPACITY (m²/l)
Normal Contrast	1 + 9	2 min.	1,8
Increased Contrast	1 + 6	2 min.	2 ½
Decreased Contrast	1 + 12	2 – 3 min.	1,4
Fast Development	1 + 4	1 – 1 ½ min.	3,6
Rapid Access Dev.	1 + 2	½ – ¾ min.	5
Processor, Machine	1 + 4	individual	individual

GENERAL NOTES:

CHEMISTRY | DILUTION | TIME | INTERVAL:
